

Fitting Instructions – Atlantic Magnetic Euro Sashlock with adjustable strikeplate

AML190E

Date Modified: 20/09/2022

Last modified by: Brock H

For best results when fixing a Sash lock follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

- X1 Sash lock
- x1 Strike plate
- X1 Face plate for strike plate
- X4 Screws
- X1 Dust box

- 1) First, mark out the desired position for the Sashlock on the door.
- 2) Next, mark out for the mortice cut out.
- 3) Then, drill/router the mortice for the lock body.
- 4) Next, using the Sashlock, mark out the position for the euro profile and spindle.
- 5) Then, drill for the euro profile and spindle positions with the correct backset.
- 6) Insert the lock into the mortice hole and mark out the faceplate.
- 7) Now, router the recess for the faceplate on the edge of the door.
- 8) Then, fix the lock using the screws provided.
- 9) Test for the euro profile and spindle position.
- 10) Once this is installed, using a combination square, measure and mark the position of the Sashlock tongue on the door frame
- 11) Then, mark the position of the strike plate, covering where the tongue will land on the door frame.
- 12) Now, router out for the dust box and strike plate and fix in place using screws provided.
- 13) Test to ensure deadbolt and latch tongue are aligned with strike plate.