

Fitting Instructions – Tupai Rapido CurvaLine Lever on Round Rose

Date Modified: 20/09/2022

Last modified by: Brock Hutchins

For best results when fixing Tupai Rapido RetaLine Levers on Long Rose follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

- X2 Lever
- X2 Round Rose
- X2 Cassette
- X1 8mm spindle
- X2 Ware washers
- X1 3mm Allen key
- X2 M6 Grub screws
- X2 M4 x 50mm bolt through fixings
- X1 Paper template
- 1) First, mark out the desired position of the lever on the door.
- 2) Install latch of your specification sold separately
- 3) Drill/router aperture for the spindle.
- 4) Take the roses and cassettes and separate the 2 components and place the roses in a safe place.
- 5) Using the cassette and the included paper template, mark out for the lugs on the cassette do this for both sides of the door, ensuring that you pay attention to handing of the cassette, ensuring that the levers will work in the desired handing.
- 6) drill out all the way through the door with an 7.5 or 8mm drill bit on the marked lug locations.
- 7) Place both cassettes on the door and fix using 2no M4 x 50mm bolts ensuring they are level with each other, and tight up to the door.
- 8) Place spindle through the cassette in the correct orientation, and then attach the outer rose over the cassette by slipping the top on first, and then firmly pushing the bottom of the rose until it goes into place with an audible click. This can be done with either the spindle removed or installed.

9) Take the leaver and pre thread the grub screw and place the ware washer on the collar of the lever.
10) Place lever onto the rose and push tight into the door and remove all slack in the grub screw.
11) Repeat steps 9 and 10 for the other side
12) Fully tighten the grub screws using the included Allen key – when tightening the 2 nd grub screw, ensure that both levers are pushed as tight to the door as possible, to lessen the risk of the levers falling off the door late on.