

Fitting Instructions – AGBT(finish)

AGB TOUCH MANGNETIC CATCHER

Modified: 31/03/2023

Last modified by: Brock Hutchins

For best results when fixing an AGB TOUCH follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

- X1 Lock Body
- X1 Magnetic Keep
- X1 Faceplate
- 1) First, measure up the location of the catcher on the side of the door.
- 2) Next, mark up the outline of the catcher face plate on the side of the door.
- 3) Then, measure the size of the catcher body and drill out depth for the catcher to sit into the door.
- 4) Now, using the markings of the catcher face plate, router out the recess for the depth of the face plate.
- 5) Test that the catcher body should now be able to sit in the door with the face plate flush to the door edge.
- 6) Now, place the catcher back into the door and screw it in place to secure the body to the door.
- 7) Drill out the depth of the magnetic section (of the keep).
- 8) Now, router out the depth of the keep face plate. It is recommended that if you multiple catchers to fit you make a jig for this.
- 9) Screw the magnetic keep back to the door frame. Ensure that this sits flush with the door frame, and then test for functionality.



