

Fitting Instructions – Sashlock Rebate Kits

ALKREBS3LK(finish)

Date Modified: 15/07/2024

Last modified by: Brock H

For best results when fixing a rebate kit follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 Rebate Block

X1 Strike Plate

X4 Screws

Follow fitting instructions for fitting a Sashlock and then use the next steps.

- 1) Using the lock position on the door, offer up the rebate block and fasten it into place using the screws provided.
- 2) Next, using the lock (not included) transfer the tongue location to the other door.
- 3) Then, place the strike plate in the desired location and rebate out for the dust box (not included) and the strike plate.
- 4) Test fit the strike plate to ensure the fit is correct.
- 5) When satisfied with the fit, fasten into place using the remaining screws provided.