

Fitting Instructions – Atlantic Premium Wall Mounted Door Stop on Concealed Fix Rose

ADSWP

Date Modified: 10/08/2022

Last modified by: Alice W

For best results when fixing a wall mounted door stop follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 30mm screw

X1 Plug

X1 Doorstop

- 1) First mark our desired position of door stop on the wall.
- 2) Next, unscrew the door stop from the rose.
- 3) Using the correct drill bit, drill for the plug.
- 4) Insert the plug into the hole.
- 5) Fix the rose to the wall using included 30mm screw.
- 6) Then, screw the door stop back onto the rose.
- 7) Finally, ensure the door stop is in the desired position.