

Fitting Instructions – Atlantic Lever Action Flush Bolt

AFB FUSHBOLT

Date Modified: 17/08/2022

Last modified by: Brock H

For best results when fixing a flush bolt follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 Flush Bolt

X1 Flush Bolt Face Plate

X6 Screws

- 1) First, mark out the desired position for the flush bolt on the desired position of the door.
- 2) Then, mark out the face plate of the flush bolt.
- 3) Using the appropriate router bit, router out a rebate for the flush bolt cover plate.
- 4) Now, use an appropriate router bit, and router out a groove which should allow enough space for the flush bolt mechanism.
- 5) Next, dry fit the flush bolt and check the mechanism is in working order.
- 6) Then, fasten the flush bolt to the door using the 4 of the screws provided.
- 7) When the door is closed, operate the flush bolt. This should have left a mark on the door frame.
- 8) Using the mark made, drill out a hole for the bolt ensuring there is enough clearance to operate proficiently and check that the bolt is engaged.
- 9) Now, create a rebate for the face plate and fasten it into place using the remaining screws provided.
- 10) Finally, test bolt.