

Fitting Instructions – Atlantic Kick Plate Pre Drilled with screws 690 x 150

AKP690

Date Modified: 20/09/2022

Last modified by: Brock H

For best results when fixing a kick plate follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 Kick Plate

X8 Screws

- 1) First, mark out the desired position of the kick plate on the bottom of the door. Make sure to leave 2mm clearance between the bottom of the kick plate/door.
- 2) Now, centralise the kick plate with the door.
- 3) Then, drill out pilot holes for the screws.
- 4) Finally, fasten into place using the screws provided and make sure to remove the protective covering.