

Fitting Instructions – Atlantic 3 Lever Key Deadlock (CE) 2.5"

ALKDEAD3LK25

Date Modified: 10/08/2022

Last modified by: Alice W

For best results when fixing a Deadlock follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X1 Deadlock
x2 Keys
X1 Faceplate
x1 Keep
X4 Screws
X1 Dust box

- 1) First, mark out the desired position for the Deadlock on the door.
- 2) Next, mark out for the mortice cut out.
- 3) Then, drill/router the mortice for the lock body.
- 4) Next, put the faceplate onto the lock body and mark out the position for the keyway.
- 5) Then, drill the keyhole position with the correct backset.
- 6) Insert the lock into the mortice hole and mark out the faceplate.
- 7) Now, router the recess for the faceplate on the edge of the door.
- 8) Then, fix the lock and the faceplate using the screws provided.
- 9) Test for the keyhole position.
- 10) Once this is installed, use the key to engage the deadlock outside of the door frame.
- 11) Mark the position of the deadbolt onto the architrave.
- 12) Transfer the marks created from the deadbolt to the rebate.
- 13) Then, mark the position of the keep.
- 14) Now, router out for the dust box and keep faceplate and fix in place using screws provided.
- 15) Test to ensure deadbolt is aligned with keep.