

## Fitting Instructions – Atlantic Pull Handle Back to Back Fixing Kit

# APHBBF25R

Date Modified: 17/08/2022

Last modified by: Brock H

For best results when installing a back-to-back fixing kit follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

X2 Threaded Back to Back Fixing Bolts

X2 Spacers with keyway

X2 Spacers with no keyway

X4 Washers

X2 Plastic Sleeves

X1 Fixing Tool

- 1) Using the shorter side of the threaded back-to-back fixing bolts, fasten them into one of the pull handles for the door.
- 2) Now, place the spacer with no keyway over the head of the threaded back-to-back fixing.
- 3) Then, insert bolts through the holes previously made for the pull handle. Refer to the fitting instructions for the pull handle in use.
- 4) Next, ensure that the washers have been placed between the door and the spacer and that the plastic sleeves have been placed over the long portion of the threaded bolt.
- 5) Using the spacer with keyway, place it over the protruding side of the threaded back-to-back fixing bolt and insert the bolt into the other pull handle.
- 6) Using the fixing tool provided, insert into the spacer with the keyway and turn clockwise until the pull handle is tight up to the door.