

## Fitting Instructions – Atlantic Solid Brass Surface door bolt (4", 6", 8")

### **ASB[4-6-8](finish)**

Date Modified: 03/01/2023

Last modified by: Brock Hutchins

For best results when fixing a surface bolt follow these instructions.

Atlantic UK recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

- X1 surface bolt
- X1 staple keep
- X1 flat plate keep
- X1 angle plate keep
- X6 screws (4- and 6-inch bolts)
- X8 screws (8-inch bolt only)

- 1) First, mark out the desired position of the surface bolt on the door.
- 2) Next using a drill and a suitable sized drill bit, drill pilot holes for the surface bolt in the correct locations.
- 3) Now using a drill or screwdriver fix the bolt onto the face of the door using the screws provided.
- 4) Adjust if needed.
- 5) Using the tongue of the surface bolt mark out where the keep needs to be located.
- 6) Using the suitable keep for the application mark out for the keep.
- 7) Next, remove material as needed to make the keep register in the desired location on the door frame.
- 8) Drill pilot holes for the keep and fasten in place using the rest of the screws provided.