

## Fitting Instructions – Deadbolt

# ASDB DEADBOLT

Date Modified: 23/05/2022

Last modified by: Alice W

For best results when fixing a Dead Bolt follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

- 1) Separate out all components supplied as follows:
  - X1 Deadbolt with Face Plate
  - X2 Deadbolt Keep Plates (rectangular and circular)
  - X1 Dust Box
  - X4 Screws
- 2) First, mark out the desired position for the Deadbolt on your door.
- 3) Then, drill out a 25mm hole for the Deadbolt to sit and create a hole through the door for the WC spindle.
- 4) Insert the Deadbolt into the pre-drilled hole.
- 5) Select either the rectangular or circular keep plate.
- 6) Mark out the position of the Deadbolt Keep Plate on the frame.
- 7) Offer the Keep Plate over the marked position and draw around the outline.
- 8) Next, cut out the previously marked area (allowing space for the dust box to sit) in the door frame.
- 9) Insert the dust box and the Keep Plate and secure with the remaining 2 screws provided.