

Old English Fitting Instructions – Mortice Knobs

Old English – Mortice Knobs – OE60

Date Modified: 04/05/2022

Last modified by: Alice W

For best results when fixing Old English Mortice Knobs (OE60) follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

- 1) Separate out all components supplied as following:
 - 2xKnobs including a grub screw each
 - 2xBackplates (located on the back of knob)
 - 1xAllen Key
 - Pack of 8 screws
 - 1xSpindle
- 2) Release grub screw from the knob head prior to fixing and keep all of the components in a safe place
- 3) Install your chosen latch into the door. For best results use the Atlantic 4" Latch (AL4)
- 4) Insert the spindle provided through the pre-drilled holes in the door, centralize the spindle in the door and mark the spindle to indicate the edge of the door.
- 5) Put the rose onto the spindle and then thread the knob on.
- 6) Repeat on the other side of the spindle/door.
- 7) Insert the screws provided through the rose and into the door to secure in place.
- 8) Finally, use the Allen key to tighten the grub screws onto the spindle.