

## Fitting Instructions – Deadbolt

# ADBRCE RADIUS TUBULAR DEADBOLT

Date Modified: 02/05/2022

Last modified by: Brock H

For best results when fixing a Dead Bolt follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

- 1) Separate out all components supplied as follows:
  - X1 Deadbolt
  - X1 Deadbolt Face Plate
  - X1 Deadbolt Keep Plate
  - X1 Dust Box
  - X4 Screws
- 2) First, mark out the desired position for the Deadbolt on your door.
- 3) Then, router out a hole for the Deadbolt to sit using an appropriate router bit (including space for faceplate) and create a hole through the door for the spindle.
- 4) Insert the Deadbolt into the pre-routed hole.
- 5) Now, insert the faceplate onto the Deadbolt using 2 of the screws provided to secure it to the door.
- 6) Mark out the position of the Deadbolt Keep Plate on the frame.
- 7) Offer the Keep Plate over the marked position and draw around the outline.
- 8) Router out the shallow mortice for the keep face plate using an appropriate router bit.
- 9) Next, cut out for the dust box.
- 10) Insert the dust box and the Keep Plate and secure with the remaining 2 screws provided.