

## Fitting Instructions – ADG Atlantic Door Guard

# ADG(finish)

Date Modified: 23/05/2023

Last modified by: Brock Hutchins

For best results when fitting the Atlantic Door Guard, follow these instructions.

Atlantic UK recommends this product is fitted by a qualified joiner.

Before starting to fit this product, please check you have the following contents

- 1) Separate out all components supplied as follows:
  - x1 Door side – Solid component
  - x1 Frame side – Component with a moving part
  - x8 screws
- 2) Mark out the desired location of the Door side of the door guard on the door.
- 3) Mark out the locations of the fixing holes, and using a suitable drill bit, drill out a pilot hole for the screws.
- 4) Then offer up the Frame side to the desired location and fix it in place using 4no. of the screws provided.
- 5) Next, offer up the door side of the door guard up into place. The correct location for this is where the ball of the door side is in between the 2 horns that are on the frame size.
- 6) When this is in the correct location, mark out and pilot hole the correct location.
- 7) Fix this in place.
- 8) Test and adjust as necessary.