

## Fitting Instructions – Atlantic Horizontal Bath lock

# ALKHZB

Date Modified: 09/05/2023

Last modified by: Brock Hutchins

For best results when fixing a Horizontal lock follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

- X1 Horizontal lock
- X1 Face plate
- x1 Strike plate
- X4 Screws
- X1 Dust box

- 1) First, mark out the desired position for the Horizontal lock on the door.
- 2) Next, mark out for the mortice cut out.
- 3) Then, drill/router the mortice for the lock body.
- 4) Set the handing of the latch tongue by following the separate instructions provided in the box.
- 5) Next, put the faceplate onto the lock body and mark out the position for the spindles.
- 6) Then, drill for the bathroom and standard 8mm spindle positions with the correct backset.
- 7) Insert the lock into the mortice hole and mark out the faceplate.
- 8) Now, router the recess for the faceplate on the edge of the door.
- 9) Then, fix the lock and the faceplate using the screws provided.
- 10) Test for the bathroom and 8mm spindle position.
- 11) Once this is installed, insert a Turn and release (not provided) to engage the deadbolt outside of the door.
- 12) Then remove the Turn and release.
- 13) Mark the position of the deadbolt onto the architrave (including the latch tongue).
- 14) Transfer the marks created from the deadbolt to the rebate.
- 15) Then, mark the position of the strike plate.
- 16) Now, router out for the dust box and strike plate and fix in place using screws provided.
- 17) Test to ensure deadbolt and latch tongue are aligned with strike plate.