

Fitting Instructions – SMART LATCH

SMART TUBULAR LATCH

Date Modified: 12/07/2022

Last modified by: Alice W

For best results when fixing a SMART LATCH follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

- 1) Separate out all components supplied as follows:
 - X1 Latch
 - X1 Latch Face Plate
 - X1 Latch Keep Plate
 - X1 Dust Box
 - X4 Screws
- 2) First, mark out the desired position for the Latch on your door.
- 3) Then, router out a hole for the Latch to sit (including space for faceplate) and create a hole through the door for the spindle.
- 4) Insert the Latch into the pre-routed hole.
- 5) Now, insert the faceplate onto the Latch using 2 of the screws provided to secure it to the door.
- 6) Mark out the position of the Latch Keep Plate on the frame.
- 7) Offer the Keep Plate over the marked position and draw around the outline.
- 8) Next, cut out the previously marked area (allowing space for the dust box to sit) in the door.
- 9) Insert the dust box and the Keep Plate and secure with the remaining 2 screws provided.