

Fitting Instructions – AWCD(finish) & AWCR(finish)

DISABLED WC TURN WITH INDICATOR (AND WITHOUT)

Date Modified: 27/03/2023

Last modified by: Brock H

For best results when fixing a Deadlock follow these instructions.

Atlantic recommends this product is fitted by a joiner.

Before beginning installation, check the product is as required/ordered.

Separate out all components supplied as follows:

- X1 WC turn
- X1 Turn Cover
- X1 Release
- X1 Release cover
- X1 5mm spindle
- 4x Screws

- 1) First, mark out the desired position for the turn and release on the door.
- 2) Next, mark out and drill the aperture for the spindle, taking the backset from the deadbolt you have selected, sold separately.
- 3) Place the spindle in the deadbolt installed in the door, and place the turn and release on the spindle, having removed the cover from the turn and release.
- 4) Push the turn and release tight up to the door and mark out for the fixings.
- 5) Remove turn and release and drill for the fixings with an appropriately size drill bit.
- 6) Repeat this for the other side of the door.
- 7) Place the release on the spindle and fix using 2 of the screws provided, using the 2 pivot holes you just drilled.
- 8) Place turn side onto the door and fasten onto the door using 2no of the screws provided.
- 9) Test to ensure the turn and release works correctly.