

Tupai Rapido 5S line lever on round rose

Date Modified: 20/09/2022

Last modified by: Brock Hutchins

For best results when fixing the Tupai Rapido 5S line lever on rose, follow these instructions.

- 1) First, mark out the desired position of the lever on the door.
- 2) Install latch of your specification – sold separately
- 3) Drill/router aperture for the spindle.
- 4) Using the cassette and the included paper template, mark out for the lugs on the cassette – do this for both sides of the door, ensuring that you pay attention to handing of the cassette, ensuring that the levers will work in the desired handing.
- 5) Drill out all the way through the door with a 7.5 or 8mm drill bit on the marked lug locations.
- 6) Place both cassettes on the door and fix using 2no M4 x 50mm bolts ensuring they are level with each other, and tight up to the door.
- 7) Take the lever and pre thread the grub screw.
- 8) Place spindle through the cassette in the correct orientation, and then attach the lever and rose over the cassette by lining up the lever and rose with the cassette and pushing it onto the cassette evenly with an audible click. This needs to be done with the spindle in place.
- 9) Place lever onto the rose and push tight into the door and remove all slack in the grub screw.
- 10) Repeat steps 8 and 9 for the other side
- 11) Fully tighten the grub screws using the included Allen key – when tightening the 2nd grub screw, ensure that both levers are pushed as tight to the door as possible, to lessen the risk of the levers falling off the door late on.