

Technical Data Sheet

atlantic uk
architectural hardware

SPCWC (finish) SENZA PARI® WC TURN & RELEASE

Product Code	SPCWC (finish)
Product Name	Senza Pari® WC Turn & Release
Product Description	WC Turn & Release to suit Senza Pari® Designer Door Lever
Product Base Material	Zinc Alloy
Available Finishes	Satin Nickel/Polished Nickel (SNNP) Satin Nickel (SN)

Other Information

To be cleaned using a soft damp cloth. Chemicals, solvents or abrasives will damage the applied finish. Supplied with 2x Bolt through Fixing, Wood Screws, 5mm x 5 mm x 75 mm Split Spindle, 1 x Loctite coated Grub Screws & Allen Key. This product requires a bolt through fixing method therefore this must be fitted with ADBCE or ASDB Deadbolts only.

10 Year Mechanical Guarantee subject to fitting requirements.

Dimensions

Width/Height: 55mm
Depth: 10mm
Projection: 40mm

Product Image



Finish Photographed: Satin Nickel

Care of Finish

In the unusual event of this product failing mechanically, we will replace it free of charge, providing you can supply us with the faulty product and a receipt to show proof of purchase. If the items are not fitted in accordance with the fitting instructions, in a correct application, this may not apply.

Products have an applied finish, and we do recommend regular cleaning with a soft cloth. If necessary, you may moisten the cloth, with water. If this is not effective in removing accumulated deposits, try using a PH-neutral soap on a soft cloth, then remove the soap immediately after application, with the help of a clean, moist, soft cloth. Under no circumstances should you use an abrasive/hard tool, chemical, acidic or abrasive substance to clean these products. This will break down the applied finish. The finish may chip or scratch if subjected to impact from sharp items such as keys and jewellery. Atlantic UK retains the right to send items away for chemical testing to analyse if the product has come into contact with any abrasive or chemical substance before issuing replacements.

Please be aware that in environments where there are high concentrations of chemicals in the air, for example from the use of low-quality paint or corrosive agents, corrosion and damage may occur to the surface of the product. Products should therefore not be fitted in such environments, until the high concentration of chemicals in the air has subsided.

the finish matters